


Air Cylinder Kits for

Fontaine Fifth Wheel Sliding Brackets


Repair

Cylinder kit (CYLNWB)




NWB Slide

Item	Description	Qty.
②	Spacer bushing	2
④	1/2" 13 Grade C hex lock nut	
⑤	1/2" x 1-1/2" hex bolt	2
⑨	Composite Air Cylinder	1




Cylinder kit (CYLLWB)



LWB Slide

Item	Description	Qty.
③	Bushing	2
⑥	Hex nut, lock 1/2"-13, low profile	2
⑨	Hex head bolt, 3/8" 16 x 1-1/2", grade 5	2
⑩	Linkage, LWB	2
⑬	Composite Air Cylinder	1




Cylinder kit (CYL-LWO-LWI)




LWO Slide

Item	Description	Qty.
③	Spacer Bushing	2
④	3/8-16 x 1.25" Hex Bolt	2
⑦	Lock Nut, 3/8-16	2
⑧	Composite Air Cylinder	1



Cylinder kit (CYL-COMP)




ATB Slide




AWB Slide

Item	Description	Qty.
⑩	Composite Air Cylinder	1
④	Flat head socket, 1/2" -13 x 1-1/2", grade 5	1
⑭	Flat washer, 1/2" I.D., 1-3/8" O.D., plain	2
⑫	Hex lock nut, 1/2" -13, grade "C"	2
⑮	Bushing, 7/16"	2




Reuse Hex bolt ①

Cylinder kit (CYL-XAWX)



AWX Slide

Item	Description	Qty.
①	Bushing, 5/16"	3
②	Hex Bolt, 1/2"-13 X 1"	2
③	Hex Bolt, 1/2"-13 X 1.5"	1
④	Hex jam nut, 1/2" -13, grade "B"	1
⑤	Hex lock nut, 1/2" -13, grade "C"	3
⑥	Washer 1/2"	3
⑦	XHD Air Cylinder	1



KIT-AIR-COIL

Parts required to connect the air actuated fifth wheel or fifth wheel air sliders to the air system.

